










# Electrolux

Dynamica  
Dynamica Pro  
Dynamica Pro Plus



\* Applies to certain models only | 僅適用於特定型號 | 仅适用于特定型号 | Berkenaan dengan model tertentu saja | Chỉ áp dụng cho một số kiểu máy | ใช้กับเครื่องใช้ไฟฟ้าบางรุ่นเท่านั้น | 특정 모델에만 적용



R Recommended nozzle | 推薦噴頭 | 推荐喷嘴 | Nosel yang disarankan | đầu hút được khuyến nghị | หัวดูดคุณที่แนะนำ | 권장 노즐

